

## Solcon - installatiekaart - AVM FRITZ!Box 7360 (v2) veranderen van netwerknaam en wachtwoord voor draadloos internet

STAP 1) Sluit de AVM FRITZ!Box aan zoals in de verkorte handleiding is vermeld.

STAP 2) Maak een bedrade of draadloze verbinding met uw FRITZ!Box:

- Bedraad: Sluit met de bijgeleverde netwerkkabel een PC aan op netwerkpoort LAN 2

of

- Draadloos: Maak verbinding met het draadloze netwerk met netwerknaam (SSID) "FRITZ!Box Fon WLAN 7360" en met het wachtwoord dat onder op uw modem staat vermeld als "WLAN Network Key (WPA2)"

STAP 3) Browse met uw internet browser naar fritz.box (of naar 192.168.178.1)

STAP 4) Klik onderin het scherm op "View: Standard". Dit wordt dan View: Advanced

The screenshot displays the FRITZ!Box 7360 web interface. At the top, there is a blue header with the FRITZ! logo and the text "FRITZ!Box 7360". Below the header, the user is logged in, and there are navigation links for "FRITZ!Box", "FRITZ!NAS", and "MyFRITZ!". The main content area is divided into several sections:

- Overview:** Shows the device name "FRITZ!Box Fon WLAN 7360", the current power consumption (40%), and the FRITZ!OS version (05.60-26937, Lab version).
- Connections:** Lists connected services: Internet, IPv4, IPv6, and Telephony (1 telephone number enabled).
- Interfaces:** Lists active interfaces: DSL, LAN, WLAN, DECT, and USB.
- Convenience Features:** Lists features like Telephone book, Wireless LAN guest, Storage (NAS), and Parental control.
- Calls (today 0):** Shows "No calls" and a "more (0)..." link.
- Network:** Shows "more (1)..." link.
- Answering Machine:** Shows "Answering machine disabled" and "No messages found".

At the bottom of the interface, there is a footer with the text "View: Advanced | Contents | Manual | Newsletter | avm.de".

## Solcon - installatiekaart - AVM FRITZ!Box 7360 (v2) veranderen van netwerknaam en wachtwoord voor draadloos internet

STAP 5) Selecteer “WLAN - Radio Network” en vul bij “Name of the wireless radio network (SSID)” de gewenste netwerknaam in en druk op “Apply”

The screenshot shows the FRITZ!Box 7360 web interface. The top navigation bar includes the FRITZ! logo and the model name. Below the navigation bar, there are links for TR069-dc56b725, FRITZ!Box, FRITZINAS, MyFRITZ!, and a help icon. On the left, a sidebar menu lists various settings categories: Overview, Internet, Telephony, Home Network, WLAN (selected), Radio Network (sub-selected), Radio Channel, Security, Schedule, Guest Access, Repeater, DECT, and System. The main content area is titled "Radio Network" and contains the following text: "Your FRITZ!Box can make a wireless radio network available at your location. You can assign any name desired to this radio network. As soon as the radio network has been enabled, wireless devices are welcome to log on to it. The list of the known wireless devices is displayed so that you can edit and restrict access." Below this, there are several configuration options: "Wireless radio network enabled" (checked), "Name of the wireless radio network (SSID)" (input field with placeholder "<uw netwerknaam>"), "Name of the wireless radio network visible" (checked), "Enable AVM Stick & Surf" (checked), and "MAC Address" (08:96:D7:1B:27:6A).

STAP 6) Selecteer “WLAN - Security” en vul bij “Network key” het gewenste wachtwoord in en druk op “Apply”

The screenshot shows the FRITZ!Box 7360 web interface, specifically the Security configuration page. The top navigation bar and sidebar menu are identical to the previous screenshot. The main content area is titled "Security" and has two tabs: "Encryption" (selected) and "WPS Quick Connection". Below the tabs, there is a heading "Specify here how your WLAN radio network should be secured against unauthorized use and monitoring." followed by three radio button options: "WPA encryption (highest security)" (selected), "WEP Encryption (not recommended, insecure)", and "non-encrypted (not recommended, unprotected)". Below this, there is a section titled "WPA encryption" with the text "Define a network key. This network key is used to secure wireless LAN connections. The key must be between 8 and 63 characters in length." The "WPA mode" is set to "WPA + WPA2" and the "Network key" is an input field with placeholder "<uw wachtwoord>" and a note "15 character(s) entered". At the bottom of the page, there are buttons for "Print Preview", "Apply", "Cancel", and "Help". The footer of the page includes the text "View: Advanced | Contents | Manual | Newsletter | avm.de".